

1951 Ford F-1 Panel Truck

Thank you for purchasing our kit. We offer articles and video tutorials on our website that focus on the basics such as painting, assembly, and preparation of 3D printed items. Additionally, product spotlights and other interesting model railroad related articles and videos are available on our website.

Visit us at custommodeldepot.com

The 1951 Ford F-1 Panel Truck from Custom Model Depot is an accurate representation of the prototype, scaled to actual dimensions.

The basic requirements for building the kit are 400 grit sandpaper, cyanoacrylate glue (super glue), an Xacto Blade, and Gloss Mod Podge. Using gloss Mod Podge, dilute with water to a water like mixture. With a small brush, apply the mixture to the edge of the opening. Next, with tweezers, place the window into the opening. Release the window from the tweezers and let the window glazing settle into the opening. The water tension of the mixture will mostly position the window glazing. You can move the glazing around with a damp brush to position the glazing and remove extra glue.

WARNING:
This kit is not a children's toy.
Not made for kids under 14 years old.

WARNING:
CHOKING HAZARD
Not for small children

